



# PAPERSYSTEMS

## Standard "EZ-BULK" Assembly



Step 1

EZ-BULK arrives knocked down flat. The lid is pre-formed and the liner is pre-installed in the bottom pad. The lid, bottom, pad, and liner are referred to as the cartridge.



Step 2

Use the pallet as a force of resistance to help form the octagonal base.



Step 3

Position the body of the container on the pallet. Make sure the evacuation hole is over the corner of the pallet.



Step 4

Nose the bottom cartridge with pre-installed liner into the octagonal body. Line up the bottom evacuation with the evacuation hole on the body.



Step 5

Hang the liner from the fill bridge. Lock in top fill fitment into fill bridge. You are now ready to begin filling.



Step 6

Band the container to the pallet 4 times total; 2 bands each direction vertically. This is marked on the lid of the EZ-Bulk. **MUST** use 3/4" steel banding or equivalent. Use edge protectors.